

Shipper: MaxPlus PharmaPack SP (SKU # 1RPPV48-4)

Products: Specialty Pharmacy Products (2-8°C)

Materials Needed: MaxPlus PharmaPack Shipper, Coolant NI-W8L9 (x2), Coolant CI-W7L8 (x2)

### Packaging assembly illustration:

- Phase Change Coolant:


- o NI-W8L9 (x2) (7.5" x 8.5" x 1")



- o CI-W7L8 (x2) (7" x 8" x 1")



### Coolant Pre-conditioning for Summer Shipping:



- 2 x Coolant NI-W8L9 (**White brick with Blue marking – Nordic Ice**) stored in the freezer (below -10°C) for a minimum of 24 hours
- 2 x Coolant CI-W7L8 (**White PCM Pouch**) stored in the freezer (below -10°C) for a minimum of 24 hours

To pack the shipper, take out all frozen coolants from the freezer and condition them laying flat on a benchtop for 30 minutes at room temperature.

**Note:** Make sure that the frozen pouches and bricks are frozen solid before removing them from the freezer. Don't stack the pouches on top of each other on the benchtop.

## Pack-out Instructions for Summer Shipping:

**Step 1:** Open the lid of the flexible insulation and insert one **frozen Coolant NI-W8L9** brick (white/blue) into the shipper.

**Step 2:** Insert one **frozen Coolant CI-W7L8** pouch (white) on top of the frozen coolant NI-W8L9.


**Step 3:** Insert the **payload** on top of the frozen coolant CI-W7L8 pouch.

**Step 4:** Insert the second **frozen Coolant CI-W7L8** pouch (white) on top of the payload.

**Step 5:** Place the last **frozen Coolant NI-W8L9** brick (white/blue) on top of the second frozen coolant **CI-W7L8**.

**Step 6:** Close the lid and use packaging tape to seal the box.

## Coolant Pre-conditioning for Winter Shipping:



- 2 x Coolant NI-W8L9 (**White brick with Blue marking – Nordic Ice**) stored in the refrigerator (between 2°C to 8°C) for a minimum of 24 hours

- 2 x Coolant CI-W7L8 (**White PCM Pouch**) stored in freezer (below -10°C) for a minimum of 24 hours

To pack the shipper, take out frozen coolants from the freezer and condition them laying flat on a benchtop for 30 minutes at room temperature.

**Note:** Make sure that the frozen pouches are frozen solid before removing them from the freezer. Don't stack the pouches on top of each other on the benchtop.

### Pack-out Instructions for Winter Shipping:

**Step 1:** Open the lid of the flexible insulation and insert one **refrigerated Coolant NI-W8L9** brick (white/blue) into the shipper.

**Step 2:** Insert one **frozen Coolant CI-W7L8** pouch (white) on top of the refrigerated Coolant NI-W8L9.

**Step 3:** Insert the **payload** on top of the frozen Coolant CI-W7L8 pouch.

**Step 4:** Insert the second **frozen Coolant CI-W7L8** pouch (white) on top of the payload.

**Step 5:** Place the last **refrigerated Coolant NI-W8L9** pouch (white/blue) on top of the second frozen Coolant CI-W7L8 pouch.

**Step 6:** Close the lid and use packaging tape to seal the box.